

RESET DEVICE

To reset a Water leak sensor hold the button for 10 seconds

